

Setting the Size Switch – Smart Drive Series 8 Machines.

Whenever you have replaced a motor controller or display board on these machines, you will need to set the size switch within the memory of the PCB. If you do not do this, the board will return a fault code 9.

To enter Size Switch setting Mode, turn the machine on at the wall but off at the console. Hold down the 'Temperature Up' button and press power. The machine will beep 4 times and the LED patterns will change.

For a 5Kg or 5.5Kg machine press the 'Wash Temp Up' button until the Cold LED is ON.

For a 6.5Kg machine press the 'Water Level Up' button until the Low Led is ON.

For a 7.5Kg machine press the 'Spin Speed up' button until the Hold LED is ON.

Then press Power to exit this mode, and the setting will be stored into the memory of the machine.